
MOUNTING INSTRUCTIONS - WISHBONE HALL STAND

W1001





Cleaning and maintenance

Polished stainless steel surfaces should be cleaned with a microfiber cloth, glass cleaner or other non-abrasive and gentle agents. Use a soft dry cloth to wipe dry.

Practical information

In the case of manufacturing defects, please contact the store where the product was purchased. Always remember to bring your receipt.

Material: Polished stainless steel, powder coated steel

Design: busk+hertzog

Dimensions: Diameter: Ø350 mm Height: 1750 mm Weight: 17 kg






Exclusion of liability

FROST accepts no liability whatsoever for damage to persons or property that occurs or has occurred as a result of improper installation or maintenance, particularly if the safety instructions and other points to note listed are not or have not been observed in full.

MOUNTING INSTRUCTIONS FOR WISHBONE HALL STAND


W1001

First, mount the wishbones by screwing them on each of the three bars.




Then, mount the three bars on the pedestal with the bolt from underneath. Securely tighten the bolts.

For easy mounting we recommend that you place the pedestal on the edge of a table, and mount it there.



We recommend that you mount the bars so that the three wishbones form a symmetrical triangle as depicted.



Topview